



Xede Wiring Diagram 2006 Mazda 3 MPS

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

XEDE Configuration:	H
XEDE Revisions:	All
XEDE Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

* One or both of the chassis grounds must be connected if any of the following XEDE features are to be used: Water spray, Boost control, Auxiliary injector drive.

** Red wire in 3 core shielded cable

DO NOT terminate the shield wire in the 3 core cable.

There are 2 black wires, DO NOT use the black wire from the shielded cable unless specifically instructed.

